



NOTE:
LAG BOLT INSTALLATION
 Prebore lag bolt holes using two diameters, one for the shank and one for the threads. The lead hole for the shank is to be 1/16" larger than the shank diameter and is to be bored to the depth of penetration of the shank. The lead hole for the threaded portion is to be 70% of the bolt diameter as shown and is to be bored at least to the length of the threads. DO NOT DRIVE LAG BOLTS WITH A HAMMER.



TREATED TIMBER BRIDGE REPAIRS BANNER CREEK #1 (1876-0.30) STANDARD GLU-LAM TIMBER BRIDGE CURB	
Date: <u>1/15/14</u>	DRAWING NO. R1913
Approved: <u>Eric Baugh</u> Forest Engineer	SHEET 3 OF 3