


Field Protocol Manual

Aquatic and Riparian Effectiveness Monitoring Program

Regional Interagency Monitoring for The Northwest Forest Plan



2012 Field Season

Contacts	3
Acknowledgements	3
Introduction	3
Locating and establishing the start of the survey	5
Navigating with the Garmin Colorado 400t.....	5
Selection Criteria	5
Record the site UTM coordinates	7
Monument the site	8
Photo Documentation	9
Additional photos to take	11
The Photo Log data form	11
Order of events for photographs at Tran A.....	11
Order of events of photographs at Tran K	11
Site Layout.....	11
Transect layout.....	14
Site Maps.....	17
Unusual situations	18
Side Channels	20
Using the Laser and Electronic Compass	24
Initial laser setup.....	24
Using the prism pole and adjusting to survey hard to reach spots	24
Channel Morphology	26
Bankfull Width (note all references to stream directions are looking downstream)	26
Change in Elevation	27
Order of events for shooting laser and prism	30
Pools.....	31
Pool Length and Residual Pool Depth.....	31
Entrenchment	33
Physical Habitat	35
Substrate – Pebble Counts.....	35
Pebble counts.....	35
Percent Surface Fines on Pool Tails	37
Large Wood	39
Measuring Stream Shade.....	43
Biological Sampling	45
Benthic Macroinvertebrates.....	45
Invasive Species.....	47
Aquatic plants	47
Aquatic animals.....	47
Terrestrial plants	48
Terrestrial animals	48
Incidental invasives	49
Vertebrates	51
Terrestrial Amphibians	51
Photographs of Biota	52
Placing and Retrieving Thermographs	54
Appendix A – Contingency Protocol for Broken Compass & Laser.....	56
Appendix B - Invasive Species Disinfection Protocol.....	58
Appendix C– Procedure for Pressing Plants	61
Appendix D – Species list and corresponding species codes.....	62
References	66

Contacts

For information about the Aquatic and Riparian Effectiveness Monitoring Program, please contact the following:

Steve Lanigan – Team Lead	503.808.2261	slanigan@fs.fed.us
Peter Eldred – GIS Analyst	541.750.7078	peldred@fs.fed.us
Mark Isley – Database Manager	541.750.7081	markisley@fs.fed.us
Heidi Andersen – Fisheries Biologist	541.750.7067	hvandersen@fs.fed.us
Mark Raggon – Field Coordinator	541.750.7021	mraggon@fs.fed.us
Steve Wilcox – Cartographic Technician	541.750.7122	sewilcox@fs.fed.us

Acknowledgements

The Aquatic and Riparian Effectiveness Monitoring Program would like to acknowledge the following people for contributing to the field protocols described here. Nate Dachtler, Kirsten Gallo, and Chris Moyer developed the original protocols and produced the first draft of this document. Erik Moberly and Devin Simmons worked on early details of the original protocols. Kris Fausti, Jenni Dykstra, Ted Sedell, Peter Gruendike, Jake Chambers, Steve Wilcox, Heidi Andersen, Hank LaVigne, John Speece, Jeff Metzger and Mark Raggon helped improve subsequent drafts of the protocol. Thanks to all of the field crew members who tested, questioned, and provided feedback over the years. Steve Lanigan (AREMP), Kate Dirksen, Emily Hall, Deanna Vinson and Jeremiah Heitke from the PACFISH/INFISH Biological Opinion (PIBO) Effectiveness Monitoring Program kindly shared their artistic drawings. Thanks to PIBO for cooperating to standardize a core set of sampling methods.

Finally, thanks to all those who have provided funding and logistical support over the years including the U.S. Forest Service (USFS) Regions 5 and 6, the Bureau of Land Management (BLM), the National Park Service (NPS), National Oceanic and Atmospheric Administration (NOAA)- National Marine Fisheries Service (NMFS) and the Environmental Protection Agency (EPA).

Introduction

The Northwest Forest Plan, hereafter referred to as “the Plan”, was approved in 1994. The Plan includes an Aquatic Conservation Strategy that requires the protection, rehabilitation, and monitoring of aquatic ecosystems under the Plan’s jurisdiction (USDA-USDI 1994). The Aquatic and Riparian Effectiveness Monitoring Program (AREMP or the monitoring plan) was developed to fulfill these monitoring requirements. The primary purpose of AREMP is to determine the current condition of 6th-field watersheds and track changes in watershed condition over time. A total of 250 watersheds will be monitored under AREMP. One of the most important aspects of the program is the collection of consistent data throughout the Northwest Forest Plan area to provide comparative data used to assess watershed condition.

The field data collected is combined with upslope and riparian information to determine watershed condition. Condition is determined using a decision support model that evaluates individual indicators and then aggregates the evaluation scores. The stream

data collected in the field represent about 2/3 of the data included in the decision support model. As natural variance both within and between the watersheds is quite high, it is imperative that errors due to sampling and observer bias are minimized. The data collected will be used as the basis for management decisions throughout the Pacific Northwest. These data comprise one of the largest data sets that exist, both spatially and temporally. Therefore, it is of the utmost importance to make the effort to produce the highest quality data possible. This document is addressed in section 11.1 Standard Operating Procedures of the Quality System Management Plan (Palmer, in prep).

The goal is to efficiently and safely collect the best data possible within a watershed.

Locating and establishing the start of the survey

A topographic map of each watershed will be supplied, marked with potential sample sites. Select sites in numerical order, omitting sites that cannot be sampled. For watershed re-surveys, survey sites will be repeated in numerical order from lowest to highest number. If additional sites need to be added, select sites in numerical order, starting with number 1 (regardless of the numbers of previously surveyed sites).

Note: A crew leader has the authority at any time to exclude a site if he/she feels it is unsafe for a crew to sample.

Use the topographic map and GPS unit to find the approximate location of the site from the road. Approach the site from downstream, using the “where to?” feature on the GPS unit to guide you toward the Transect A flag. If the Transect A flag cannot be located, use the waypoint to locate the start of the site. If the start point appears to be located on a hill slope, continue up the stream channel, watching both the distance from the site and its location on the hill slope relative to the GPS pointer. The goal is to find the location on the stream that is the smallest possible distance from the GPS waypoint. This will be the start point of the survey.

Navigating with the Garmin Colorado 400t

1. To access the “Where To?” Menu:
 - a. Select Shortcuts > Where To?
 - b. Select the preferred search category (usually Waypoints or POI).
 - c. Select a point. A green circle containing the word “GO” appears at the bottom of the page.
 - d. Press Enter.
2. To navigate to a point on the map:
 - a. On the Map page, use the Rock ‘n Roller to move the pointer to a location and press ENTER, a green circle containing the word “Go” appears at the bottom of the page.
 - b. Press ENTER.
3. During navigation, select Shortcuts > Compass and follow the red arrow.

Selection Criteria

Exclude a watershed if:

1. It is deemed dangerous for a survey crew to be working in the area (i.e., law enforcement personnel identify a watershed as having prevalent drug growing operations). *Safety*.
2. Fire activity blocks or limits road/trail access to the watershed or has potential to spread, endangering the crew while working in the stream. *Safety*.
3. Less than 25% of the total stream length is located on federal land (done in office). *Ownership*.
4. A minimum of sampling four sites cannot be completed within six days (the length of time available each sampling trip) due to time constraints, accessibility issues, or site constraints (see below). *Accessibility*.

Exclude a site if:

1. The site is not safely accessible; i.e., it cannot be reached without putting the crew in danger. (A long hike into a steep canyon does not qualify as a dangerous situation for the crew.)
2. The site is not wadeable because of depth or current.
3. Travel time (round trip) from road camp or wilderness camp is over four hours to get to and from the site. The crew should never be in the position of hiking back to camp or their truck in the dark. If the watershed is large and sites are spread out, a crew will relocate camp to be closer to outlying sites to reduce daily travel time.
4. The GPS point (used to identify the beginning of a site) is located on private land.
5. The GPS point for a site is located in a lake, wetland or marsh, or on a dam or glacier.
6. The site is an artificial stream or irrigation canal.

Include a site if:

1. All stream channels will be considered, regardless of the presence or absence of flowing water. Use the following criteria to determine whether the site should be sampled;
 - a. Active scour must be present in the channel, i.e., fine particles have been removed or pushed to the side and larger substrate is visible. Ephemeral streams that flow over vegetation are not sampled.
 - b. There must be **well-defined bankfull indicators** present to sufficiently establish survey transects throughout the length of the site, signifying that it is an active channel. An active channel will have some combination of the following bankfull indicators:
 - i. Examine stream banks for an active floodplain. This is a relatively flat, depositional area that is commonly vegetated and above the bankfull elevation.
 - ii. Examine depositional features such as point bars. The highest elevation of a point bar usually indicates the lowest possible elevation for bankfull stage. However, depositional features can form both above and below the bankfull elevation when unusual flows occur during years preceding the survey. Large floods can form bars that extend above bankfull whereas several years of low flows can result in bars forming below bankfull elevation.
 - iii. A break in slope of the banks and/or change in the particle size distribution from coarser bed load particles to finer particles deposited during bank overflow conditions.
 - iv. Locate the elevation where mature key riparian woody vegetation exists. The lowest elevation of birch, alder, and dogwood can be useful, whereas willows are often found below the bankfull elevation.
 - v. Examine the ceiling of undercut banks. This elevation is usually slightly below the bankfull elevation.

- vi. Stream channels actively reform bankfull features such as floodplains after shifts or down cutting in the channel. Be careful not to confuse old floodplains and terraces with the present indicators.
- c. The survey crew must be able to physically work and collect a full set of data within the stream channel. Avoid sites choked with willows (or similar dense vegetation) that excessively hinder the crew's productivity or restrict mobility while working in the channel.
- d. In order to sample for macroinvertebrates the site must have; a minimum wetted width of 1 meter, a minimum depth of 0.1 meter and riffle habitat present.

Note: Do not, under any circumstances, walk on private land to access sites. Your presence on private land is considered trespassing, regardless of what you are doing.

Record the site UTM coordinates

GPS points will be taken at the end of the survey at or near transect K.

Garmin Colorado 400t:

1. Select Shortcuts > Others > Waypoint Averaging > Options > Create Waypoint.
2. When the Sample Confidence reaches 100%, select Save.
3. Edit waypoint name (Shortcuts > Waypoint manager) and enter the new waypoint using the following naming convention: a 5 letter watershed code, a 4 number site code, and a Transect location A or K. (Example: ORRCK1003A or ORRCK1003K). If the site is a QA/QC or trend site, place a 9 or a 6 in front of the site number (e.g., ORRCK9003A, ORRCK6003A).
4. Edit waypoint symbol to **Bar**.
5. Enter the UTM coordinates in the field data recorder.

Garmin Map 76s:

1. Press and hold the ENTER/MARK button for two seconds.
2. On the "Mark Waypoint" screen, toggle to the waypoint number and enter the new waypoint number as follows: a 5 letter watershed code, a 4 number site code, and a Transect location A or K. (Example: ORRCK1003A or ORRCK1003K). If the site is a QA/QC or trend site, place a 9 or a 6 in front of the site number (e.g., ORRCK9003A, ORRCK6003A).
3. Hit the MENU button, scroll to Average Position, then hit ENTER.
4. For the Y&GA location, place the GPS unit at or near Transect A and let the unit log at least 250 measurements (ORRCK1019A).
5. For the Y&GK location, place the GPS unit at or near Transect K and collect at least 40 measurements (ORRCK1019K).
6. Once all the measurements have been recorded, press ENTER, scroll to the DONE box, and press ENTER.
7. Enter the UTM coordinates in the field data recorder.

Monument the site

Site markers are used to monument the site location. The markers will assist others in finding the start of the original site. ***Site markers will not be placed in designated wilderness areas and National Parks.***

1. Locate a distinct feature near the bottom of the site for Tran A and near the top of the site at Tran K that will be easily identified by the next survey crew.
 - a. Something relatively permanent such as a piece of large wood near the stream (e.g. a large spanner, snag, or tree).
 - b. Sometimes riparian zones within the sites are characterized by a continuous patch of vegetation; try to pick something that stands out such as a large clump of sage or one conifer near the start of the site.
2. Attach one of the markers to your chosen spot.
 - a. Use an aluminum nail to attach the marker. Make sure the marker is clearly visible and facing the stream.
 - b. Place flagging at the top and bottom of the marker. If the tree or log that the marker is attached to is too large to tie flagging around, hang a piece above the marker tying it to the nail or nearby branch.
3. If the marker is more than 10 meters from the Transect, take a GPS point and make a note in the Monument Description data form.
4. Next, standing at the marker location, take a manual compass bearing from the marker to Transect A/K Left Bank. Record this bearing in the field data recorder, as well as on the left side of the marker using a permanent pen.
5. Record the following information on the site marker in permanent pen (Figure 1);
 - a. Watershed Code (i.e. ORRCK)
 - b. Site Number (i.e. 1022)
 - c. Compass bearing and direction to Transect A/K Left Bank (i.e. 345° NNW)
 - d. Date (i.e. 22 August 2009)
 - e. Surveyor ID (i.e. FNG01)
 - f. UTM's for Transect A/K (i.e. 10T 0479344 4934553)
 - g. Reach length for the site.
 - h. TR or BR (Top or Bottom of reach)

**Note: When revisiting trend sites that have an existing site marker, add any missing information, then retrace the existing information with permanent pen.*

6. Measure the distance from the marker to bottom of the site and record (this will be done with the laser and prism by taking a point at Left Bank).

The following points will be labeled as Transect Y:

- Next, take a laser shot of the prism pole at the base of the monument at transect A (Y&MA).
- Next, take a shot of the prism pole at the left bankfull on Transect A, independent of transect shots (Y&LB). After the M1 gradient shot, take a shot of the prism pole at the base of the monument at Tran K (Y&MK).

- Finally, before traversing back downstream after finishing the survey, take a shot of the GPS location established at or near Transect K (Y&GK).
7. Take a picture of the marker location and surrounding distinctive features. This will include a minimum of three pictures; 1) facing Transect A Left Bank standing at the monument 2) facing the monument standing at Transect A Left Bank and 3) a view of the monument from the route a crew will take to approach the site.

The image shows a schematic of a site marker form. The form is rectangular and contains the following text and graphics:

- Title:** Aquatic & Riparian Effectiveness Monitoring Program
- Address:** 4077 Research Way, Corvallis OR 97333
- TR:** (Transect)
- 345° NNW** (with label **c** pointing to it)
- 22 August 2009** (with label **d** pointing to it)
- FNG01** (with label **e** pointing to it)
- AREMP** (with a fish icon in a circle next to it)
- 10T 0479344 4934553** (with label **f** pointing to it)
- 240m** (with label **g** pointing to it)
- Watershed Code** ORRCK **Site** 1022 (with label **a** pointing to the Watershed Code field and label **b** pointing to the Site field)
- Bottom text:** This site is part of a long-term project to assess watershed condition. Please do not disturb this monument.
- Bottom graphics:** A row of seven geometric shapes: an inverted triangle, a circle, another circle, a rectangle, another circle, another inverted triangle, and a pentagon.
- Other labels:** Labels **h** and **b** point to the top right corner of the form.

Figure 1. Schematic of site marker with required information filled out.

Photo Documentation

Information about each site will be documented in photographs and in the field data recorders. Four photos (1 left bank, 1 downstream, 1 right bank, 1 upstream) will be taken at Transect A and K of each site. In addition, photographs should be taken of rare or unique features in the site including culverts, logjams, beaver dams, or vertebrates that are difficult to identify.

The digital photos collected in the field prove invaluable when relating individual sites to watershed condition. These photos bring to life much of the data collected in the field and allow this information to be relayed to the public in a way that can be more readily understood. AREMP will use these photos in several different ways. They will be linked to GIS, which will allow for more meaningful interpretation of the field data. These photos will be retaken at 5-year intervals, which will provide a means to discern changes in the area over time.

The crews will be responsible for taking photos in the field, including the photos taken at Transects A and K and photos of the monuments at both the top of the reach (TR) and the bottom of the reach (BR). It is possible that due to the position of satellites or the depth of the canyon you are in, you will not be able to get GPS coverage. In this case, walk around the area where you will be taking pictures in an attempt to obtain satellites.

1. Turn on your camera and do the following:
 - a. Verify the image quality is set on "SUPERFINE". Hold down the Func. Button.
 - b. Verify the image size is set on "L". Hold down the Func. Button.
 - c. Verify that the date and time on the camera are correct. Press Menu then press the right arrow to bring up the settings menu.
2. At the beginning of each day, open the screen on the GPS unit that displays the time and take a photo of it with the digital camera. This photo serves as a backup in case the digital camera clock varies.
 - a. On the GPS unit Section Menu, select *Status*.
 - b. On the Sub-section Menu, select *UTC Time*. This is Greenwich Mean Time, for Pacific Daylight time subtract 7 hours.
 - c. You should now be viewing a screen showing time and date.
 - d. Take a picture of this screen, attempting to minimize glare. Look at the picture on the viewfinder to ensure that the numbers on the GPS unit can be read.
3. Take a series of photos standing in the middle of the **bankfull channel** (midway between left bank and right bank, regardless of wetted channel) at Transect A and K.
 - a. The first photo taken should be of the white board (for Tran A only), which will then be placed on the left bank.
 - b. Take the second picture of the left bank (where the white board is); rotate the camera clockwise 90° to take the next photo, which will be of the downstream view.
 - c. Repeat 2 more 90° rotations to capture the right bank and the upstream view.
 - d. Ask all other crew members to stay out of the photos. Gear in the photos is OK as long as it does not move between pictures. Keep gear bundled up to avoid the "yard sale" look.
4. The **white board** should contain the following information:
 - a. Location (i.e., watershed code name and site number): For Site 3 on Wadeable Creek in Oregon, you would put "ORWAD1003" or ORWAD9003 (6003) for QAQC and trend.
 - b. Date (Day Month Year): "3 July 2003"
 - c. View: "LB Transect A."

Additional photos to take

Take photos that will help give people who may never visit the area an idea of what it looks like. These photos should help show the condition of the areas sampled, species captured at each site, land disturbances, etc. Take pictures of the following:

- Features such as logjams, waterfalls, deep pools, and beaver dams.
- Land disturbances such as fires, landslides, extensive blow downs, etc.
- Unusual species and species that are difficult to identify; this info should also be entered into the photo log and incidental spreadsheets along with the photo number (see the photographs of Biota).
- If possible, take a picture of the overall watershed (from a road/clearing).
- Scenic shots and photos of people working are good as well.

The Photo Log data form

In the field data recorder, enter the appropriate information detailing the site ID (ORWAD1003), the UTM coordinate, the date, the photographer, and the photo number. In the comments section, describe the subject of the photo (e.g., transect photo, unidentified salamander) the habitat or other distinguishing features of the biota. Enter each picture taken at a site into the photo log.

Order of events for photographs at Tran A

1. GPS screen showing date and time
2. Close-up of white board with site information
3. Transect A left bank with whiteboard
4. Downstream from Transect A
5. Transect A right bank
6. Upstream from Transect A
7. Transect A left bank from monument.
8. Monument from Transect A left bank
9. Approach to monument
10. Any other additional photos needed to capture distinctive features

Order of events of photographs at Tran K

1. Transect K left bank
2. Downstream from Transect K
3. Transect K right bank
4. Upstream from Transect K
5. Monument from Transect K left bank

Site Layout

1. Examine the bankfull indicators (described below) throughout the site to identify the bankfull elevation. Recognize that all six indicators are rarely present at an individual site.


- Examine stream banks for an active floodplain. This is a relatively flat, depositional area that is commonly vegetated and above the current water level.
 - Examine depositional features such as point bars. The highest elevation of a point bar usually indicates the lowest possible elevation for bankfull stage. However, depositional features can form both above and below the bankfull elevation when unusual flows occur during years preceding the survey. Large floods can form bars that extend above bankfull whereas several years of low flows can result in bars forming below bankfull elevation.
 - A break in slope of the banks and/or change in the particle size distribution from coarser bed load particles to finer particles deposited during bank overflow conditions.
 - Define an elevation where mature key riparian woody vegetation exists. The lowest elevation of birch, alder, and dogwood can be useful, whereas willows are often found below the bankfull elevation.
 - Examine the ceiling of undercut banks. This elevation is usually slightly below the bankfull elevation.
 - Stream channels actively attempt to reform bankfull features such as floodplains after shifts or down cutting in the channel. Be careful not to confuse old floodplains and terraces with the present indicators.
2. Measure the bankfull width **perpendicular to the channel** at Transect A (Figure 2). Round the bankfull width to the nearest 0.1 meter. This number will be used to determine the location of two additional bankfull width measurements.
 3. Two additional bankfull widths will be measured, one upstream and one downstream. For example, the initial bankfull width was 5.3 m, go upstream 5.3 m and take a bankfull width measurement. Repeat this procedure going downstream from the initial bankfull width location to get one more bankfull width measurement. If the situation arises where a bankfull width cannot be measured on the downstream end of Transect A, take the additional measurement above Transect A.

Note: If a qualifying side channel is encountered while acquiring the 3 bankfull widths, measure the bankfull width of the side channel and add it to the bankfull width of the main channel.

4. Record the three bankfull widths and calculate the average. Use the average to determine the width category (Table 1 - this information is also provided in the field data recorders). The site length is defined for each width category and is equal to 20 times the bankfull width.
5. If the watershed has been surveyed before the original bankfull width will be used to determine site length but still record three bankfull widths in the data recorder.

Trend and QAQC Sites (i.e. repeat sites):

Measure and then record the three bankfull widths in the Nomad field data recorder. The reach length used for surveys will be the same as measured in the previous survey and will be provided to crew leaders prior to leaving the office. If a crew conducts a repeat visit to a site that was previously surveyed in 2002, they will use the reach length from the 2002 data. For QAQC sites, the site length will be from the previous stint. Transect distance are calculated by dividing the total reach length by 20.



Measurement 1	5.0M
Measurement 2	4.5M
Measurement 3	4.0M
Add the 3 measurements and divide by 3	$13.5/3=4.5$
Take the average number and find the site length in Table1	160M

Figure 2. Schematic of the three bankfull measurements taken to determine site length and an example of how to calculate site length.

Table 1. Average bankfull width categories with corresponding site length.

Average Bankfull Width in meters	Width Category	Site Length in meters
1 to 8	8	160
8.1 to 10	10	200
10.1 to 12	12	240
12.1 to 14	14	280
14.1 to 16	16	320
16.1 to 18	18	360
18.1 to 20	20	400
20.1 to 22	22	440
≥22.1	24	480

Transect layout

In all sites, 11 transects will be laid out and should be labeled A-K. In addition to the 11 major transects, 10 intermediate transects will be flagged with **orange** flagging and used for pebble counts and thalweg locations (Figures 3 and 4). Side channels and pools will also be identified and marked with **pink** and **blue** flagging respectively. Transect A will be marked with **biodegradable** orange flagging.

Determine the site length as described in the previous section and divide the site length by 20 to obtain the increment between each transect.

For example, the distance between transects in a 160m reach is $160/20=8\text{m}$ (Table 1).

Following the thalweg (defined as the deepest path of flowing water in the main channel), measure the distance between transects using a meter tape. The meter tape should be laid on the surface of the water at the thalweg while measuring. Place an orange flag in an obvious area near eye level at each transect location. Label the flags with the corresponding transect name (A, B, C...K). Label the intermediate flags with the letter of the preceding transect and the number 2 (A2, B2, C2...J2).

***If a sharp bend in the channel is encountered while measuring between transects, split the measurement at the apex of the bend in order to accurately capture the channel length.*

***Remove all flagging from the site (except for the Transect A flag) after the survey is completed. Keep the flagging to reuse for future surveys.**




Figure 3. Site layout and tasks performed at major and intermediate transects.




Figure 4. Location of biological surveys performed in a site.

Site Maps

A site description map will be drawn on a template located on the Algiz field computer (Figure 5). The focus should be to capture any special features of a site and to aid in monument description, so it is important to keep the maps simple and concise. There will be an additional template for sites containing side channels (Figure 6). Examples of features to capture: large log jams, culverts, monument location, waterfalls, roads.




Figure 5. Example of site map in a site **without** qualifying side channels.




Figure 6. Example of site map for a site **with** side channels.

Unusual situations

Since stream channels come in a variety of sizes and shapes, situations will frequently arise that are not addressed in this protocol. In this case, the crew leader should make the best logical decision and document the situation in the notes section of the Comments section on the Headings page on the Nomad. Unusual situations include the following; details are presented in Table 2:

Obstructions at the waypoint

If the waypoint is located on or close to an obstruction (large culvert or log jam), move the start of the site upstream to the nearest surveyable location.

Impassible barriers

If you encounter an impassible barrier (waterfall, lake or glacier) or private land **during site layout**, establish the end point of the survey at the barrier (Transect K). Using the transect distances established from the 3 initial bankfull measurements, layout the site traveling downstream to Transect A.

Overlapping sites

Always survey the lowest numbered site first. Transect K of the first site will be flagged as Transect A for the second site. Drop the second site if the first site will overlap more than 50% of the second site's length. In order to determine this you will have to measure the 3 initial bankfull widths for the second site. Overlap is measured from the site's original GPS coordinate.

Small Obstructions

Occasionally logjams or other obstructions cover the stream channel making it impossible to measure transects and capture bankfull. If the obstruction is small and blocks only one transect, move the transect to the nearest suitable location and make a comment in the Stream Data Form. Avoid moving the transect more than 2 meters up or downstream. If the obstruction is large and blocks numerous transects, it should be excluded from the survey. Use a stop/start survey in this situation.

Culverts

If a culvert is located within a site and it does not interfere with data collection (a transect does not fall on the culvert), take a point at the bottom of the culvert then move to the other side and take a point at the top. Label these points as "CV" in the field data recorder. Under no circumstance should you ever pick up and move the laser without shooting a new origin (AKA "Traverse").

Stop and Start of Survey

Stop and start is a technique intended for large obstructions (i.e. passable waterfall or large/long culverts) encountered in the site that interfere with data collection or compromise crew safety.

If there is an unsurveyable obstruction within the site, such as a large log jam, passable waterfall, large/long culvert, stop the survey at the obstruction and restart the survey upstream of it. Capture points with the laser at both the bottom and top of the obstruction and label them with the longitude they occur in, as well as “Stop Survey” (SP) or “Start Survey” (SS). Enter a comment of (Waterfall = WF, Culvert = CV, Log Jam = LJ) in the field data recorder for these points. Steps to deal with this situation if encountered are as followed;

1. Begin site layout as previously described.
2. When the obstruction is encountered, measure the distance to the beginning of the obstruction. Place flagging labeled “STOP SURVEY”.
3. Go to the upstream end of the obstruction and, at the first surveyable location, hang a flag labeled “START SURVEY.” Continue measuring up to the next transect location.
4. Collect a point at both the “STOP SURVEY” and “START SURVEY” flagging and make notes in the comments section on the Algiz 7field computer form.

Table 2. Unusual situations and appropriate actions.

Situation	Action
Culverts “CV”	
Less than 4 times Bankfull width category in length	If it does not interfere with data collection (a major transect does not fall on the culvert) refer to the note on culverts in the “Unusual Situations” section. If it does interfere with data collection, perform a Stop and Start. (Refer to Stop and Start of Survey section.)
Greater than 4 times Bankfull width category in length	Relocate start of site.
Large Logjams “LJ”	
Less than 4 times Bankfull width category in length	Stop and Start. (Refer to Stop and Start of Survey section.) This is only used if the logjam prevents the collection of data. (I.e. if a <u>major</u> transect cannot be moved a reasonable distance to avoid the logjams effect on data collection.)
Greater than 4 times Bankfull width category in length	Relocate start of site.
Impossible waterfall (for crew)	If it does not interfere with collection of data (does not prevent layout of at least 2 transects), include in survey. Do this only if it is determined safe for the crew. If not, do a Stop and Start. If one transect falls on the waterfall, adjust the transect location either above or below the waterfall (whichever is closer and is safe for the crew to survey).
Passable waterfall (for crew) “WF”	If the waterfall prevents collection of data, Stop and Start. (Refer to Stop and Start of Survey section.)

Side Channels

A side channel is any channel separated directly from the main channel by an island with an elevation above bankfull. All transects (both intermediate and major) that are affected by a side channel will be marked with an additional pink flag that is labeled with the channel number (in case of overlapping multiple channels). Place the pink flag adjacent to the orange transect flag in the main channel as well as one within any qualifying side channels at the transect location. Both the inlet and outlet of each qualifying channel will be flagged as well.

1. Only side channels that begin and end within the site will be considered (Figure 7; SC-D does not qualify).
2. A side channel begins (and ends) at the location where it becomes separated from the main channel by an island (Figure 8: see SC-E). SC-G is considered part of the main channel because the water is split by a gravel bar which is below bankfull.
3. The following criteria must be met in order for a side channel to be included in the survey:
 - a. There must be clearly defined bankfull indicators at some point along the side channel.
 - b. The bankfull width of the side channel must be $\geq 20\%$ of the bankfull width category (Table 3). Measure the bankfull width of the side channel at 25%, 50%, and 75% of the way, up from the downstream end. Average the results and compare to the site's average bankfull width. In Figure 8, SC-B, C, and E would qualify, and SC-F would not as it is too narrow.
 - c. The side channel must enter and leave the main channel within the site.
4. Do not collect measurements in discontinuous side channels, where at any location (normally at the upstream end) the side channel **bed elevation** is higher than the bankfull elevation of the main channel.
5. Channels that do not meet the above criteria are not included in the survey.

Measurements in qualifying side channels will include large wood, pebble counts, streambank measurements and wetted widths.

Table 3. Minimum bankfull width for qualifying side channels.

Average Bankfull Width in meters	Width Category	Minimum average bankfull width for qualifying side channel
1 to 8	8	1.6M
8.1 to 10	10	2.0M
10.1 to 12	12	2.4M
12.1 to 14	14	2.8M
14.1 to 16	16	3.2M
16.1 to 18	18	3.6M
18.1 to 20	20	4.0M
20.1 to 22	22	4.4M
≥22.1	24	4.8M




Figure 7. Numbering side channels and rotating transects at each channel. Major transects B - I are represented by the dashed lines and are labeled on the right. Channels are numbered by the order in which they are encountered in the site, while moving upstream. A channel does not need to enter the main channel or have water to qualify (side channel 4), as long as it meets the criteria for a side channels listed previously.




Figure 8. Examples of side channels. Channels B, C, and E are considered side channels ($\geq 20\%$ of the bankfull width category) whereas channel F is excluded as it is too narrow. Channel A is excluded, because it does not have a head (entry point) to the channel. Channels E and F depict where to take width measurements within potential channels (at 25%, 50%, and 75% of the way up from the downstream end of the portion of the island that is $\geq$ the bankfull elevation). Channel D is not included because it began outside of the site. Channel G is part of the main channel since the bar is below the bankfull elevation.

Using the Laser and Electronic Compass

The laser rangefinder and electronic compass are used to accurately measure a variety of physical habitat attributes, such as; bankfull width, bankfull width to depth ratio, pool length, residual pool depth, gradient, and sinuosity. In addition, these instruments are used to create a map of the stream channel. For a more comprehensive guide on setting up and using these instruments consult the AREMP Electronics Protocol.

Initial laser setup

Set the laser and tripod up in a location that provides a clear line of site to the first transect and longitudinal. It is best to minimize the number of times the laser needs to be moved. When setting up the laser, the middle tripod pole should be **fully extended** and standing on a hard flat surface (usually a rock). Mark this center point with an "X" using chalk so this point can be relocated if necessary. Tripod legs should be firmly dug into the ground so the tripod and laser are steady. The legs will have to be adjusted so that the unit is level, using the bubble on the tripod. Check the compass to ensure that the laser is level within 0.5 degrees, closer to zero is best. An alarm on the compass will sound if it is too far out of alignment. Conduct the compass calibration at each site location (use the AREMP Electronics Protocol compass calibration section to take you through this process). The LCD screen on the laser should always be set to HD (Horizontal Distance) and M (Meters).


IMPORTANT: Be sure the center tripod pole is firmly placed on a flat surface, and the remaining legs are secured to the ground. A reasonable method is to place a heavy rock around the tip of the tripod legs to keep the whole unit from wobbling. The end piece of the center pole should be fully extended. When entering the Instrument Height (height of center leg) be sure to read the number at the bottom of the bracket.

Using the prism pole and adjusting to survey hard to reach spots


1. Place the point of the prism pole on the substrate at the location you wish to measure with the laser and electronic compass.
2. Use the bubble level to ensure that the prism pole is oriented vertically. If the pole is leaning, it will change the location and elevation of the point that is taken.
3. The prism pole (Target Height) can be adjusted to prevent moving the laser unit. **Remind the laser operator to change the target height in the data recorder each time you change the height of the prism.** If the target height is not changed, the data will be incorrect and will require editing at a later date.
4. In the case of an undercut bank, it is important to capture the wetted edge at the point where you can see the wetted edge and shoot the point on the surface of the water only. Make a note of the undercut bank in the data recorder, and measure the distance of the undercut that is wetted.
5. In very tight situations, you may have to invert the prism pole or remove the prism from the pole and place the prism in the desired location. In this case, the rod height should be set at 0.08, the distance from the edge of the prism to the center of the glass.

When encountering an **undercut bank** measure the wetted edge by pressing the prism pole as close against the bank as possible while still keeping it level.


- It is important that the prism pole is level and the tip is held at the water's surface.
- Measure the distance to the true wetted edge under the cut bank and record it in the Recon and laser notebook.



On a vertical bank, capture the bankfull height by placing the prism head against the bank (for a 0.08 meter shot) making sure the bottom edge is level to the bankfull line.



If you encounter an undercut bank that prevents you from placing the prism at bankfull, press the prism pole (keeping it level) against the bank and suspend the tip at bankfull height. Be sure to make a note in the laser notebook or the Recon about the situation.



Channel Morphology

Bankfull Width (note all references to stream directions are looking downstream)

Bankfull width will be measured at each major transect using the compass and laser. At each major transect, ten points will be collected; Left Bankfull, Left Wetted Edge, Thalweg, Right Wetted Edge, and Right Bankfull; and five equally spaced points visually estimated at 10%, 30%, 50%, 70%, and 90% across the channel (Figure 9). If the main channel is **dry**, collect 8 points at the transect, which include Left Bankfull, deepest point in channel along transect (where thalweg would be if water was present), and Right Bankfull; and five equally spaced points estimated at 10%, 30%, 50%, 70%, and 90% across the channel. Bankfull and wetted widths will also be collected in qualifying side channels. If the side channel is dry, points will be collected at both Left Bankfull and Right Bankfull locations and at the 25% and 75% locations of the bankfull width (Figure 9). At each intermediate transect take a point at the Thalweg (in a flowing channel) or in the deepest location (in a dry channel). Be sure to place the prism pole on the streambed when taking measurements.

Special Situation: If a large boulder or log is located on an increment point and the obstruction is below bankfull elevation, collect the point on top of the obstruction. If the obstruction is above the bankfull elevation, do not collect the point at that increment and make a note in the field data recorder.




Figure 9. Example of the ten points collected at each major transect.




Figure 10. Four points will be collected on all side channel transects. If the channel is dry, place the prism at left bankfull, 25% and 75% of the bankfull width, and right bankfull. If the channel is wet, place the prism at left bankfull, left wetted edge, right wetted edge, and right bankfull.

Change in Elevation

Stream gradient is the average slope of the water's surface measured from the start of the site to the end of the site. To obtain gradient we use the change in elevation measured between left wetted at Transect A and left wetted at Transect K.

The elevation change will be measured twice, once upstream (traveling from Transect A-K) and once downstream (traveling from Transect K-A). These two elevation value differences will be averaged and used to calculate the site gradient. Using the steps listed below, recall the elevation values at both A and K left wetted (these measurements are automatically calculated in the Gradient form on the Algiz field computer) to calculate the difference and see if the two measurements are within 10% of each other. If they are not within 10%, you will measure the change in elevation a third time traveling from Transect A to K. All elevation values collected will be recorded, but no more than 3 changes in elevation will be measured.

Important: Be sure to mark where the points are taken for wetted edge at Transect A and K using a wax pencil to mark an "X" on the rock where the measurement is taken. Be very careful when working around these markers to ensure they are not moved. Water levels can raise or drop during the course of a survey. In a dry channel, clearly mark where you took the point, as well.

Dry Channels

In the absence of water, find the deepest point in the stream channel, following the transect line for both A and K (Figure 11) for gradient measurements.




Figure 11. Example of where to place the prism pole in the situation where the stream channel is dry at both Transect A and K.

The following steps outline the process for collecting the appropriate data and how to calculate the elevation change. All of the elevations are automatically populated into the Gradient Form on the Algiz field computer. At Transect A, shoot the elevation of the left wetted edge on the Gradient Form in the L1 column. At Transect K shoot the elevation for the left wetted edge in the L2 column. When the laser survey is complete, re-shoot the left wetted edge of Transects K a second time. Then, traverse downstream and re-shoot the left wetted edge of Transect A, a second time. In the field data recorder, label these points as M1 at Transect K and M) at Transect A, respectively.

The following calculations are automatically made in the Gradient Form, however, if the field data recorder fails follow these steps. Calculate the elevation change using the Z-values for each measurement as follows:

1. Calculate $L_2 - L_1 = \text{Value}_1$
2. Subtract $Z\text{Value}_1 - [0.10 * \text{Value}_1]$
3. Add $Z\text{Value}_1 + [0.10 * \text{Value}_1]$
4. Calculate $M_1 - M_2 = \text{Value}_2$
5. If the value calculated in step 4 is between the values calculated in steps 2 & 3, you are finished, otherwise go to step 6.
6. Re-shoot Transect A and K a third time.
7. Record values for N_1 and N_2 on Elevation Data Form and stop.

For example, after shooting the four points (two at each transect) you have the following values:

Point Set	Value A _#	Value K _#	Value difference	Lower 10 %	Upper 10 %
1	100.5	125.5	25	22.5	27.5
2	101.2	125.8	24.6		

If the value difference is within the 10 % range (as demonstrated in this example), then do not shoot a third set of elevation points.

Note: If Transect K is located on a dry segment of the stream, take the upper elevation points at the next major transect with a left wetted edge.

Order of events for shooting laser and prism

Triangulation of monument location

Monument at A= Y Tran, MA

Transect A left bankfull elevation = Y Tran, LB

Survey points

Transect A left bankfull elevation = Tran A, LB

Transect A left wetted edge = Tran A, LW (mark the location of this shot for elevation!!)

Transect A left wetted edge = L1 (gradient shot)

Transect A thalweg = Tran A, TH

Transect A right wetted edge = Tran A, RW

Transect A right bankfull elevation = Tran A, RB

Transect A 10%, 30%, 50% 70% 90% (wherever they fall in order between left and right bank).

Transect A2 thalweg = Tran A2, TH

Transect B.....

Transect K left bank = Tran K, LB

Transect K left wetted edge = Tran K, LW

Transect K left wetted edge = L2 (gradient shot)

Transect K thalweg = Tran K, TH

Transect K right wetted edge = Tran K, RW

Transect K right bank = Tran K, RB

Transect K left wetted edge = M1 (gradient shot)

Transect K 10%, 30%, 50% 70% 90% (wherever they fall in order between left and right bank).

Monument at K = K Tran, MK

Transect K waypoint taken with GPS = Y Tran, GK....Habitat must take point and save it on Colorado or Oregon for Crew Leader to download (save as ORRCK1003K) as well as mark point of where GPS was taken with rocks or flagging

Pools

Pool Length and Residual Pool Depth

Objectives:

- Quantify the relative length and frequency of pool habitat in each site.
- Determine the average residual depth of the pools.

Pool Criteria:

Sample every pool within the sample site that meets **ALL** of the following criteria for low flow conditions.

1. Pools are depressions in the streambed that are concave in profile, laterally and longitudinally.
2. Pools are bounded by a head crest (upstream break in streambed slope) and a tail crest (downstream break in streambed slope).
3. Only consider main channel pools where the thalweg runs through the pool, and not backwater pools.
4. Pools span at least 90% of the wetted channel width at any one location within the pool.
5. Pool length, measured along the thalweg from the head to the pool tail crest, is greater than its width. Pool width is measured perpendicular to the thalweg at the widest point of the pool.
6. Maximum pool depth is at least 1.5 times the maximum depth of the pool tail crest.

Keep in mind, the water surface gradient of a pool is typically less than the water surface gradient of the adjacent habitat units.

Note: When considering whether to lump or split two potential pools and both habitat units meet the above criteria for pools, consider them two pools if the pool tail depth of the upstream pool is similar to depths from other pools within the site. Conversely, consider it one pool if that pool tail depth is significantly deeper than other pools within the site.

Note: When islands are present, describe the habitat unit in the main channel regardless of the habitat type in the other channel.

Sampling method:

1. Place the prism pole at the deepest spot along the pool tail crest (see pool criteria #2.) to capture the pool tail crest location and label the point by the longitude it is located in, and as "Pool Tail" in the field data recorder (e.g. BC LONG, PT).
2. The maximum depth represents the deepest point in the pool and is found by probing the substrate with the prism until the deepest point is located. Label this point by the longitude it is located in, and as "Pool Max" in the field data recorder (e.g. BC LONG, PM).

3. Place the prism pole at the pool head crest (see pool criteria #2) and label this point by the longitude it is located in, and as "Pool Head" in the field data recorder (e.g. CD LONG, PH). If the pool is a plunge pool, take the point at the head crest with the prism point at the water's surface (see figure 12).
***If a sharp bend in a pool is encountered, capture extra points with the laser and prism. These will be labeled with the two letter longitudinal code that the pool is located in.*
4. Measure the pool tail crest depth on dammed pools along the top of the obstruction (mostly large wood) if all flow is going over the obstruction. Conversely, measure to the streambed if some of the water is observed flowing under the obstruction.




Figure 12. Example of a plunge pool situation in which you would measure the head of a pool where the surface of the water intercepts the bedrock/substrate.

Entrenchment

Entrenchment will be determined at all sites with less than 30 m in average bankfull width (average calculated during site determination; Table 4), and are less than 4% gradient (determined at end of the laser survey). Therefore, this task is one of the last tasks completed at a site.

		Average BF width	
		≥ 30 m	< 30 m
Gradient	≥ 4%	NO	NO
	< 4%	NO	YES

Table 4: How to determine if a site is surveyed for entrenchment.

Determine whether the site is entrenched at Transect A. If the crew cannot measure the bankfull depth at Transect A due to deep water, move upstream to the next suitable major transect.

Sampling Method (Figure 13):

1. Stretch a meter tape from the left bankfull elevation to the right bankfull elevation, ensuring that the tape is level and perpendicular to the bankfull channel. Record the bankfull width in meters (to the nearest cm, for example; 1.05m) in the Entrenchment data form.
2. Multiply bankfull width by 2.5 to determine the minimum valley width number for entrenchment (*Note: This is automatically done in the Entrenchment data form*).
3. Using a meter stick or the prism pole, measure maximum bankfull depth, from the meter tape to the substrate at the thalweg (see page 11 for definition) along the transect. Record the bankfull depth in meters (to the nearest cm, example 0.65m) in the Entrenchment data form.
4. Multiply the maximum bankfull depth by 2 to determine the flood prone elevation (*Note: This is automatically done in the Entrenchment data form*).
5. At the flood prone elevation, stretch the meter tape perpendicular to the valley walls until you reach the minimum valley width number determined in Step 2. If you touch the ground of the valley wall on **both** sides of the channel, before you reach the minimum valley width number, measure and record the valley width to the nearest cm. (The site is entrenched). If you are not touching the ground of valley wall on both sides of the channel when you reach the minimum valley width number, record the minimum valley width number. (Site is not entrenched).




Figure 13. To measure entrenchment, the bankfull elevation and bankfull depth are measured. The minimum valley width number and flood prone elevation are calculated using the bankfull width and depth. This calculation is done automatically in the Entrenchment data form of the FDR.

Physical Habitat

Substrate – Pebble Counts

Bed and bank materials of a stream are key elements in the formation and maintenance of channel morphology. These materials influence channel stability and resistance to scour during high flow events. The frequency of bed load transport can be critically important to fish spawning and other aquatic organisms that use the substrate for cover. The pebble count procedure was originally designed to quantify streambed substrate without having to collect substrate samples and take them back to the lab for sieve analysis. The procedure requires taking measurements of substrate *at increments along main channel and side channels transects within bankfull constraints*.

Pebble counts

1. Substrate will be measured at all 21 transect locations (Transects A – K; major and intermediate transects) which may extend into adjacent qualifying side channels.
2. Measure 5 substrate samples at each transect. When a single main channel is present, visually locate the 10%, 30%, 50%, 70% and 90% increment points within the bankfull width starting at left bank (See Figure 14).
3. When side channels are present at a transect, split the 5 substrate measurements between the main and side channels in proportion to their bankfull widths and adjust the measurement increments accordingly. For example, if the main channel has a 10-meter bankfull width and the adjacent side channel has a 5-meter bankfull width, take 3 substrate measurements at 25%, 50% and 75% of main-channel bankfull width and then 2 measurements at 25% and 75% of the side-channel bankfull width.
4. Without looking directly at the substrate of your sample location, step forward bringing your meter stick lightly down to touch the substrate. Reach down to the tip of the meter stick and pick up the first substrate that you touch with the tip of your finger. DO NOT LOOK while you are selecting the substrate.
5. Measure the substrate along the intermediate axis with a ruler (scale = mm). The intermediate axis is the median side (B axis) of the rock; it is not the longest side (length-wise) or the shortest side (depth) of the rock. Visualize the B axis as the smallest width of a hole that the particle could pass through.
6. If the substrate has a smooth dirt feel and is not gritty, call it silt and record it as 0.031. If it is gritty and is < 2 mm, call it sand and record it as 1.0. Anything 2 mm and greater should be measured and recorded. Bedrock (substrate 4096mm and larger) is defined as a boulder large enough to park a car on. When in doubt, measure the substrate. If you are unable to access the substrate due to a large piece of wood, enter the value -9998 on the Substrate data form. Only use the code if you are unable to get under the log. *Do not call it "wood" if it is a piece of bark or a twig.*
7. On larger boulders, you may have to use a field tape or flip the ruler end-over-end several times to get a measurement.
8. If rocks are embedded, you may have to feel for the intermediate axis with your hand and use your fingers as calipers.

9. Enter all data on the Substrate data form, starting with Transect A. Write each measurement in the appropriate blank. Only use –9998 if the wood is embedded in the substrate and it is impossible to reach under to select a pebble. If it is not possible to measure the substrate, perhaps because of a deep pool where the substrate is not visible for an ocular estimate, record –9999 for no measurement in the field data recorder.




Figure 14. Transect divided for substrate measurement.

The Substrate data form - pebbles

1. To complete the pebbles portion of the substrate form, measurements should be taken at the appropriate transects and recorded in the appropriate location.
2. Take measurements and record at all main and intermediate transects.
3. For all measurements, enter either a number (mm) or the appropriate code for type of substrate encountered.
4. For data collected in side channels, change the channel code from S1 (main channel) to the code that corresponds to the side channel (e.g. S2, S3, etc.)

Percent Surface Fines on Pool Tails

Objective:

- Quantify the percentage of fine sediments on the surface of pool tail substrate.

Where to take measurements:

1. Collect measurements in the **first ten pools** of each site beginning at the downstream end. Exclude beaver or man-made dam pools.
2. Sample within the wetted area of the channel.
3. Take measurements at 25, 50, and 75% of the distance across the wetted channel, following the shape of the pool tail.
4. Take measurements upstream from the pool-tail crest a distance equal to 10% of the pool's length or one meter, whichever is less.
5. Locations are estimated visually.

Sampling method:

1. Assess surface fines using a 14 x 14 inch grid with 49 evenly distributed intersections. Include the top right corner of the grid and there are a total of 50 intersections.
2. Take 3 measurements per pool.
 - a. Place the bottom edge of the grid upstream from the pool-tail crest a distance equal to 10% of the pool's length or one meter, whichever is less. Make sure that the grid is parallel to and following the shape of the pool-tail crest. (It is important to note that the pool tail crest is not always exactly perpendicular to the channel, See figure 15 below.)
 - b. Place the center of the grid at 25, 50, and 75% of the distance across the wetted channel, making sure the grid is parallel to and following the shape of the pool-tail crest.
 - c. If a portion of the fines grid lands on substrate 512mm or larger in size, on the b-axis, record the intersections affected as non-measurable intersections (Fig. 16).
3. Record the number of intersections that are underlain with fine sediment < 2 mm in diameter at the b-axis. Place a 2 mm wide piece of electrical tape on a ruler and use this to assess the particle size at each intersection.
4. Aquatic vegetation, organic debris, roots, or wood may be covering the substrate. First attempt to identify the particle size under each intersection. If this is not possible, then record the number of non-measurable intersections.

*Note: Your total number of measurements should **not exceed 50** total measurements per grid. I.e., you measured 20 fines under the intersections, but 30 intersections were completely covered in thick cover of macrophytes = 50. Therefore, 20 is recorded in the measured section and 30 in the non-measured column of the data sheet.*




Figure 15. Example of where to place fines grid on a pool tail at 25%, 50% and 75%.




Figure 16: In this figure, all intersections of the fines grid at the 25% placement will be counted and recorded. For the 50% placement, the intersections of the fines grid that land on the boulder will be recorded as non-measurement.

Large Wood

Objective:

- Quantify the number and size of large wood pieces that are present within the bankfull channel, including qualifying side-channels.

Sampling method:

1. In order to be counted, each piece must meet **ALL** of the following criteria.
 - a. Each piece must be greater than 3 meter in length and at least **15 cm** in diameter one-third of the way up from the base, or largest end.
 - b. Only include standing trees that lean within the bankfull channel if they are dead. Dead trees are defined as being devoid of needles or leaves, or where **ALL** of the needles and leaves have turned brown. Consider it living if the leaves or needles are green (Figure 17).

Note: Use caution when assessing the condition of a tree or fallen log. Nurse logs can appear to have living branches when seedlings or saplings are growing on them.
 - c. Wood that is embedded within the stream bank is counted if the exposed portion meets the length and width requirements.
 - d. Do not count a piece if only the roots (but not the stem/bole) extend within the bankfull channel (Figure 18).
 - e. Some pieces crack or break when they fall. Include the entire length when the two pieces are still touching at any point along the break (Only count as one piece if they are from the same original piece of wood). Treat them separately if they are no longer touching along the break. Count only the portion within the bankfull channel when they are no longer touching (Figures 19 & 20).
2. Record the piece number, estimated length (nearest 10 cm), and estimated width (nearest cm) of all pieces in the site. The same person will make all estimates for a given site.
3. Also measure the length (nearest 10 cm) and diameter (nearest cm) of the first 10 pieces you encounter. The person estimating should not be made aware of the measured value.
4. A subset of pieces will be measured at sites with more than 10 qualifying pieces of wood.
 - a. For sites estimated to have between 11 and 100 pieces, measure the first 10 pieces of wood encountered. Starting at piece number 11, measure every 5th piece of wood up to and including the 35th piece of wood. All subsequent pieces of wood will be measured every 10th piece (starting with number 45).
 - b. For sites estimated to have over 100 pieces, measure the first ten pieces, then starting at the 11th piece only measure every 10th piece.
 - c. If the piece of wood designated for measurement can not be measured safely; then measure the next piece of qualifying wood. Then continue measuring as specified above in a and b.

-

40




Figure 18. Examples of qualifying large woody debris (1). The pieces on the right side (3) are not counted because only the roots extend over the bankfull channel (upper) and the exposed section is < 3 m in length (lower).




Figure 19. Examples of how to measure the length of broken pieces. Measure the length of the entire piece on the left (pieces still connected). Only measure the piece within the bankfull channel on the right.




Figure 20. Variations of touching vs. not touching along the break.

Table 5. Codes to be used with the wood data form.

Code Type		Definition
# Pieces Touching		
S	→	Single piece
C	→	Complex (> 1 piece)
Wood Type		
N	→	Natural (broken ends or entire trees)
C	→	Cut end
A	→	Artificial (part of a man-made structure)
RN	→	Root wad attached to trunk with N atural end (broken or entire tree)
RC	→	Root wad with opposite end C ut

****Jams and accumulations will be numbered sequentially, in the order that they are encountered.**

If you do not encounter any wood on a longitude, check the box on the data form indicating there is no wood in that longitude (remember to uncheck box for the next longitude you encounter wood in).

Measuring Stream Shade

The Solar Pathfinder is used to quickly and accurately measure existing stream shade. This information will be used with data derived from satellite images of riparian vegetation to validate a shade prediction model.




Figure 21. Parts of the Solar Pathfinder

Placement of the sun-path diagram:

1. Remove the dome and place the sun-path diagram over the level-bubble frame. **Be sure you are using the correct sun-path diagram for your location** as it varies with latitude and longitude. Check the watershed map prior to starting surveys to make sure you are using the correct diagram.

Set the magnetic declination (this is done before season)

1. Magnetic declination west and east of north is marked at the top of the sun chart.
2. Pull out the declination locking tab at the base of the compass to allow the diagram to be rotated to set the magnetic declination.
3. Grab the frame of the level bubble and rotate the diagram counterclockwise to the appropriate magnetic declination, then push the lock tab in.

4. All declination values for the western U.S. are positive values on the declination number line (i.e., to the right of zero).

Measuring Stream Shade

Sampling Method:

1. Stream shade measurements will be taken at major transects A, C, E, G, I and K.
 - a. If the **bankfull** width of the transect is less than 20 meters, collect one measurement at the mid-point of the bankfull width. If the **bankfull** width of the transect is greater than 20 meters, take measurements at one-quarter and three-quarters of the **bankfull** width.
2. Set up the Solar Pathfinder at the appropriate point(s) along the Transect as described above.
 - a. Hold the unit with both hands at about one-half meter above the water's surface. Orient and level the dome, and take readings. Make a note in the Stream Shade datasheet stating that the tripod was not used at that transect.
 - b. If the water is too deep to stand in, move upstream until you reach the next mid-bankfull channel location where measurements can be taken. Make a note in the Stream Shade datasheet describing the change in location (e.g., Site moved 5 m upstream from Transect A due to water depth).
3. Ensure that the unit is level and the dome is oriented south using the compass and bubble level on the unit.
4. On the dome, follow the **August** sun-path line and observe the two small numbers between each of the vertical hour break lines. The numbers represent the percent of daily solar energy available for each half-hour.
5. Estimate the percentage of each hour line segment is shaded or blocked by shadow-casting objects.
6. Record the estimated values in the Stream Shade table on the field data recorder.

Biological Sampling

Benthic Macroinvertebrates

The benthic invertebrate protocol is the same as that described by Hawkins et al. (2001). Benthic invertebrate samples should be collected at all sites. **Collect benthic invertebrates at the start of the survey in the morning, prior to starting the survey.**

Objectives: Describe the composition and health of the macroinvertebrate community.

Where to take samples:

1. Begin sampling at the first fast-water riffle habitat encountered at the site and continue upstream to the next 3 fast-water riffle habitat units. Two samples will be collected from each of the four riffles.
2. Determine net placement within each habitat unit by generating 2 pairs of random numbers between 0 and 9 on the data logger. The first number in each pair (multiplied by 10) represents the percent upstream along the habitat unit's length. The second number in each pair represents the percent of the stream's width from river left looking downstream (RL). Each sample will be obtained from the location where the length and width distances intersect (estimate by eye).
3. Repeat this process to locate the second sampling location. If it is not possible to take a sample at one or both of these locations (log in the way, too deep, cannot seal bottom of net, etc.), generate an additional set of random numbers and sample the new location.

Sampling method:

These methods were described by Hawkins et al. (2001)

1. Collect samples using a Fixed Area Design (0.72 m^2) from fast water habitats with a $500 \mu\text{m}$ mesh net. Take invertebrate samples from 4 different fast-water (e.g. riffles, runs) habitat units. Take 2 separate 0.09 m^2 fixed-area kick net samples from each unit for a total of 8 samples. If no fast-water habitats occur, take the 8 samples from shallow, slow-water habitat units. Combine the 8 individual samples into a single sample that will be used to represent the study area.
2. Place the kick net so the mouth of the net is perpendicular to and facing into the flow of water. If there is no detectable flow, orient the net to most easily facilitate washing benthic material into the net. Collect invertebrates from within the 0.09 m^2 sampling frame in front of the net. Work from the upstream edge of the sampling plot backward and carefully pick up and rub stones directly in front of the net to remove attached organisms. Quickly inspect each stone to make sure you have dislodged everything and then set it aside. If a rock is lodged in the stream bottom, rub it a few times concentrating on any cracks or indentations. After removing all large stones, disturb small substrates (i.e. sand or gravel) to a depth of about 10 cm by raking and stirring with your hands. Continue this process until you can see no additional organisms or organic matter being washed into the net. After completing the sample, hold the net vertically (cup down!) and rinse material into the bottom of the cup. If a substantial amount of material is in the net, empty the net into the 14-

liter bucket for processing before continuing to the next sample location. Otherwise, move to the next sample location and repeat the above procedure to create a composite sample.

3. Field processing requires a 14-liter bucket, a white plastic washtub, and a 500 μm sieve. Use the bucket to decant organisms from inorganic substrates into the sieve. Use the washtub to transfer stream water into the bucket and then to visually inspect inorganic residue for heavy organisms that were not decanted.
4. Continue this process until all 8 samples have been collected and placed in the bucket. Make sure you thoroughly wash organisms from the net by vigorously pouring water down the net and into the cup. If the net has a cup at the end, remove the cup over the top of the bucket and wash it out.
5. Examine the contents of the bucket for non-native snails, mussels, or crayfish as described in the Invasive Species section below.
6. Remove and release from the bucket/washtub/sample jar all vertebrates, including fish and amphibians. Also remove and release native crayfish.
7. Add water to the bucket and decant invertebrates and organic matter from the sample by stirring the contents of the bucket and then pouring suspended material through the 500- μm sieve. Repeat this process until no additional material can be decanted. Transfer the material in the sieve (invertebrates and organic matter) into the 2-liter sample jar with a small spoon and then wash any remaining material in the sieve into the jar with a squirt bottle. Place the inorganic residue remaining in the bucket into the plastic washtub and cover with water to a depth of 1 cm. Inspect the gravel on the bottom of the tub for any cased caddis flies or other organisms that might remain. Remove any remaining organisms by hand and place in the sample jar.
8. At camp, fill the jar/s with 95% EtOH. Immediately label the jars both inside and outside. Preserve this composite sample in 1 or more sample jars depending on the amount of material collected. If there are multiple jars, label them as 1 of 2 and 2 of 2, etc. and then tape them together.

Invasive Species

Invasive species can have a multitude of effects on native flora and fauna. The presence of invasive species can indicate degraded watershed condition. All sites will be examined for the presence of any invasive species listed in Table 6. Invasive species surveys will occur at three different times (associated with other protocols) at each site and will target different species and their preferred habitats. Incidental occurrences of any non-native plants or animals should be recorded on the Incidental Invasives data form.

Aquatic plants

Sampling methods

1. During site layout, examine the wetted portion of the channel for any potential non-native invasive plants. Be sure to cover the entire site, and thoroughly examine any off-channel wetted areas as well.
2. If a non-native invasive plant is encountered, take photographs and collect specimens. Place specimens between two sheets of paper in a plant press (see Appendix D for plant press protocol). Label the paper in the plant press with watershed code, site number, date, species code, and personnel code. Try to keep specimens in a cool dark place to avoid rapid decomposition.
3. On the Aquatic Invasives data form, record the longitude segment, the species code, the jpeg number of any photographs taken, and whether or not a sample was taken of any non-native invasive plants found.

Aquatic animals

Sampling methods

1. During site layout, examine the wetted portion of the channel for any potential non-native invasive animals. Be sure to cover the entire site, and thoroughly examine any off-channel wetted areas as well.
2. After obtaining eight benthic macroinvertebrate samples in the first four fast-water riffles of the survey (as described in the Benthic Macroinvertebrates section above), empty the contents of the sample collection net into a large washtub or bucket.
3. Examine the contents of the sample for the presence of any non-native snails, mussels, or crayfish listed in Table 6 and pictured in the reference material.
4. If a non-native crayfish is found in the sample, take photographs, and then place it into a separate jar. Preserve the specimen using 95% EtOH as described in the Benthic Macroinvertebrate section of this protocol. Label the jar with watershed code, site number, species code, date, and personnel code. Record any native crayfish found in the macroinvertebrate sample on the Incidental Vert sheet, then release the native crayfish.
5. If any non-native snails or mussels are found in the sample, take photographs and enter the species code and jpeg numbers on the Aquatic Invasives data form. Place the animals back into the bucket to be processed with the macroinvertebrate sample.

6. If you found non-native species, finish decanting and preserving the eight original subsamples, and collect more samples at various locations in the site until you find more of the non-native specimens.
7. Place the extra specimens into a separate jar, preserve them with 95% EtOH, and label the jar with watershed code, site number, species code, date, and personnel code.
8. On the Aquatic Invasives data form, record the location as “Benthic Sample”, the species code, the jpeg number of any photos taken, and whether or not a sample was collected of any non-native animals found.

Terrestrial plants

Sampling method

1. Terrestrial plant surveys will be performed in longitudes A-B, F-G, J-K.
2. Left and right bank on each side of the site will be examined for 5 minutes.
3. Crew members should start at the bankfull indicator of the upper transect (B, G, K) on opposite banks, and thoroughly examine an area from the transect to downstream transect that is no more than 5 meters in width from the bankfull indicator line. If you reach the next major transect before the 5 minute search time elapses, you may continue downstream, but do not pass the next major transect where a plant survey will be performed.
4. If multiple channels occur at the search location (i.e., side channels), conduct the search on the outermost left and right banks. Do not conduct searches on islands or mid-channel gravel bars.
5. Work in a zigzag pattern for 5 minutes, examining the riparian vegetation for any non-native plants as indicated in the species list (Table 6) and the reference material.
6. When a non-native plant is encountered, pause the stopwatch and document the plant. On the Terrestrial Invasives data form, record longitude segment, the species code, the bank the plant was found on (L or R), and the jpeg number of any photos taken. Take a GPS reading at the location of the non-native plant.
7. Re-start the stopwatch and continue the survey until 5 minutes have elapsed.
8. At the end of the 5 minutes, fill out the Terrestrial Invasives data form, recording the longitude, the time, and the estimated length and width of the area searched on each bank during the survey.
4. If a suspected invasive plant species is encountered, take photographs and collect specimens. Place specimens between two sheets of paper in a plant press (see Appendix D for plant press protocol). Label the paper in the plant press with watershed code, site number, date, species code, and personnel code. Try to keep specimens in a cool dark place to avoid rapid decomposition.
9. (See Appendix D for plant press procedures).

Terrestrial animals

Sampling method

1. During the terrestrial plant survey and large wood surveys, crew members should examine the riparian area for any sign of feral swine.

2. Take photographs of any tracks, feces, or disturbed areas that would indicate the presence of feral swine. The most consistent indication of feral swine presence in the area are large dig outs, or disturbed areas that look similar to areas heavily grazed by cattle, but are lacking other signs of domesticated livestock in the area.
3. On the Terrestrial Invasive data form, record the species code, the location, and the jpeg number of any photos taken documenting the presence of feral swine.
4. Do not collect any samples of feral swine or feces (feral swine carry diseases that can infect humans).

Incidental invasives

If any plants or animals listed in Table 6 are found during other protocol surveys or while traveling to and from sites, be sure to document their presence on the Incidental Invasives data form. **Take photographs** of any specimens found and **collect samples** of any aquatic plants or animals that are encountered.

Table 6: Invasive species of concern

Type	Common name	Genus species	Species Code
Aquatic animals	New Zealand mudsnails	<i>Potamopyrgus antipodarum</i>	POAN
	Zebra mussels	<i>Dreissena polymorpha</i>	DRPO
	Quagga mussels	<i>Dreissena rostriformis bugensis</i>	DRRO
	Rusty Crayfish	<i>Orconectes rusticus</i>	ORRU
	Red Swamp Crayfish	<i>Procambarus clarkii</i>	PRCL
	Ringed Crayfish	<i>Orconectes neglectus</i>	ORNE
	Bullfrog	<i>Rana cotesbeiana</i>	RACO
	Northern Crayfish	<i>Oronectes virilis</i>	ORVI
	Nutria	<i>Myocaster coypus</i>	MYCO
Aquatic plants	Yellow Flag Iris	<i>Iris pseudacorus</i>	IRPS
	Hydrilla	<i>Hydrilla verticillata</i>	HYVE
	Parrot Feather Watermilfoil	<i>Myriophyllum aquaticum</i>	MYAQ
	Eurasian Watermilfoil	<i>Myriophyllum spicatum</i>	MYSP
	Variable-leaf milfoil	<i>M. heterophyllum</i>	MYHE
	Yellow Floating Heart	<i>Nymphoides peltata</i>	NYPE
	Giant Salvinia	<i>Salvinia molesta</i>	SAMO
	Giant Reed	<i>Arundo donax</i>	ARDO
	Brazilian Elodea	<i>Ergeria densa</i>	ERDE
	Didymo	<i>Didymosphenia geminata</i>	DIGE
	Flowering rush	<i>Butomus umbellatus</i>	BUUM
	Kudzu	<i>Pueraria lobata</i>	PULO
	Common reed	<i>Phragmites australis</i>	PHAU
	Curly-leaf pondweed	<i>Potamogeton crispus</i>	POCR
	Water primrose	<i>Ludwigia spp.</i>	LU
Terrestrial animals	Feral Swine	<i>Sus scrofa</i>	SUSC
Terrestrial plants	Japanese Knotweed	<i>Fallopia japonica</i>	FAJA
	Cultivated Knotweed	<i>Polygonum polystachyum</i>	POPO
	Giant Knotweed	<i>Polygonum sachalinense</i>	POSA
	Giant Hogweed	<i>Heracleum mantegazzianum</i>	HEMA
	Old Man's Beard	<i>Clematis vitalba</i>	CLVI
	Garlic Mustard	<i>Alliaria petiolata</i>	ALPE
	Himalayan blackberry	<i>Rubus discolor</i>	RUDI
	English Ivy	<i>Hedera helix</i>	HEHE
	Salt Cedar	<i>Tamarisk ramosissima</i>	TARA

Vertebrates

Terrestrial Amphibians

Terrestrial amphibian searches will occur at each site within specified watersheds. Above all else, care must be taken when handling organisms. Remember that amphibians absorb substances through their skin, and the chemicals in sunscreen and bug repellent will be toxic to amphibians. Under no circumstance will the crew members performing amphibian searches be wearing bug repellent or sunscreen until they have completed surveying.

1. Surveys will be performed at Transects B, D, F, H, J and K within the site. Crew members should start at the wetted edge and search their way downstream on each bank for five minutes (ten minutes total at each transect). Do not pass the next major transect downstream. Be sure to estimate the total area searched along each bank: the width (away from the wetted edge) of the area searched will be restricted to a maximum of 2 meters. (Note: the dimensions recorded are the actual meters searched, not covered.)
2. If multiple channels occur at the search location (i.e., side channels), conduct the search on the outermost left and right banks. Do not conduct searches on islands or mid-channel gravel bars.
3. During this time, roll over rocks and logs, and dig carefully through leaves and soil. Make every effort to minimize your impact on the habitat. Return rocks and logs and other objects back to their original locations on the bank.
4. When an amphibian is found, stop the time and identify and measure the organism for total length and snout to vent length, in millimeters. When returning animals to the field, place them in the same area you found them in and resume the survey. If you found the animal under a rock, place it beside the rock rather than back under the rock to avoid smashing the animal. Continue searching for the remainder of the 5 minute survey.
5. Be sure to target riparian areas along both banks between transects that amphibians might use as habitat, e.g. seeps or springs, mossy areas, or other moist, cool areas.
6. Other data to record:
 - a. Estimate the length and width of the area searched in meters, the type of habitat searched (you will enter the appropriate code on the Terrestrial Amphibian data form), and the air temperature.
 - b. If an amphibian was captured, identify 1) which bank it was caught on (left or right looking downstream), 2) habitat (ranking from most, condition of the habitat, 3) location of specimen (in/on/under) within the habitat, 4) measure snout vent length (SVL) and total length (TL) (however, do not measure the total length of frogs or toads) 5) what habitat it was in, 6) the distance from the waters edge, 7) the life history stage (juvenile or adult), and 8) any mortality information.
7. It is important to be very specific about the habitat when an amphibian is found. This can include; slope aspect, distance from stream, and the specific habitat type. Write these conditions on the comments section next to the individual amphibian captured.

Photographs of Biota

Follow these general guidelines when taking photographs of animals.

- Please be aware that you may be working with threatened or endangered species in some areas and that handling all species with care is your first priority. Keep all individuals moist and place them back into their habitat as soon as possible. Only take a picture of the animal if it doesn't put any further stress on the individual.
- Use a small object for scale (e.g., pencil, ruler, fish board).
- Avoid having people in the picture (hands or fingers are ok).
- Zoom in to capture the specimen only.
- Re-take the picture if the clarity, color, focus, angle or lighting is poor.
- It is especially important to take pictures of specimens that cannot be identified.

A picture should be taken of each new species encountered by each crew member at a site. Only take a few pictures of the representative sample of each species found at the site.

Aquatic Amphibians

1. Place specimen on its abdomen next to a ruler and capture the full length of the amphibian.
2. Also, take any pictures on the ventral and lateral side that may help further identify the individual.
3. Take a picture of any distinguishing feature about the specimen.
4. Take a picture if you can't identify the species of the animal.

Terrestrial Amphibians

1. Place active amphibians in a moist, aerated transparent bag and quickly take a picture (puff up the bag to protect the animal and place a small amount of water inside).
2. Important: do not place amphibians in a closed hand, because they are heat intolerant and may become highly metabolic, which can cause death.
3. Hold gently in moist hand that is free of bug repellent and sun screen and take abdominal picture.
4. Take pictures from all angles, so that you can capture mottling, skin color, limbs and other distinguishing features.
5. Take a picture if you can't identify the species or family.

Aquatic Snails, Mussels, and Crayfish

1. Place the specimen on something that provides a good scale reference.
2. Take pictures of the dorsal and ventral sides.
3. Take pictures of any distinguishing feature about the specimen (i.e., operculum, gills, etc.).

Aquatic and Terrestrial Invasive Plants

1. Take pictures of the entire plant, including something in the picture for scale reference.
2. Take close-up (macro) pictures of different key areas of the plant that could aid in identification (i.e., flowers, leaves, stems, roots).

Placing and Retrieving Thermographs

Thermographs are to be placed in each watershed prior to the field season by the Recon Crew. A survey crew may be asked to retrieve a thermograph at the end of the field season. Temperature data will be collected hourly from June 1 through September 15. All thermographs should be removed from the watersheds by October 15.

Thermograph location and placement:

1. The thermograph should be placed in the lower-most, accessible point of the watershed on federal land, with these exceptions:
 - a. If the federal landholdings are discontinuous, place the thermograph on the lower-most continuous portion of federal land that will be surveyed, downstream of all sites and tributaries with sites.
 - b. If the HUC is a composite watershed (a drainage basin that has water input from outside the basin) and the mainstem will not be sampled, place the thermograph in the largest tributary that will be sampled at the lower-most point on federal land.
2. Launch the thermograph on the day of placement. Make sure it begins logging prior to placement in the stream.
 - a. Program the thermograph to log temperature hourly for 331 days
 - b. Label the file with watershed name, code and year.
Example: ORSES_E_Fork_Smelly_Creek_2003
3. Secure the thermograph in the PVC pipe to a steel cable with a bolt.
4. Place the thermograph in deep, flowing water (not a pool), ideally in the thalweg or other area which will remain underwater throughout the summer. Avoid high-traffic locations.
5. Secure the thermograph under rocks and attach the cable to a tree or other anchor point. Bury the cable under rocks or wood.
6. Document the time and water temperature using a NIST-approved thermometer at the exact time the thermograph is logging a temperature. Make sure the thermograph has stabilized in the water for 5 to 10 minutes prior to the scheduled logging time.
7. Document the location:
 - a. Flag a tree 5 meters upstream or downstream of the anchor so that attention is not brought to the cable. You may want to place an inconspicuous marker at the base of the anchor point.
 - b. Get a GPS waypoint at the thermograph location, labeled with the serial number of the thermograph.
 - c. Enter detailed notes into the FDR on the location of the thermograph relative to the anchor (distance and direction) and stream channel, what it is attached to (tree, size, type, bank, etc.) and where the flag is relative to the anchor. Draw a map of its location. Be very specific so another person can follow your directions to retrieve a thermograph if necessary.
Example: *Thermograph mid-channel, under .4m boulder, 1.5m from/attached to .3m Douglas fir, right bank. Flag on willow, upstream 6m, right bank.*

- d. Take photos of the thermograph location, anchor (up close, from the flag, including the flag), the flag (from access direction 15 meters away) and any other photos that will facilitate finding the thermograph. Have one person point at the thermograph location and take a photograph.
 - e. Mark the location on the field map.
 - f. Write parking and walking directions to the site.
8. Download all waypoints from the GPS unit and photos from the camera.
 - a. Using Photoshop place arrows on one or two photographs pointing out the location of the thermograph, anchor and flagging.

Thermograph Retrieval:

1. Prior to removing the thermograph, measure the water temperature using a NIST-approved thermometer at the exact time the thermograph is logging a temperature. Enter both the temperature and time it was taken into the data recorder.
2. Remove the thermograph from the assembly and double check the serial number on the thermograph to make sure it matches the one on the data sheet.

Appendix A – Contingency Protocol for Broken Compass & Laser

Regardless of whether a compass or laser is malfunctioning, certain key pieces of data still need to be collected at a site. For this protocol the site will be laid out and all the major transects will be surveyed identically to the regular field protocol, without using the compass and laser. Contingency data forms titled “Depth, Width, Pools, SC Width and SC Depth” have been designed to facilitate and ensure these data are collected properly and completely (the crew should not leave the stream until all information is collected and recorded). Copies of these data forms are provided on the Nomad as a separate excel file (C:\Data\FieldData2012\Outgoing\Datasheets) and in the crew notebook. The Nomad will have to be used to collect the contingency data and the Algiz 7 will be used to collect Habitat data. To do this the Algiz 7 field computer settings must be properly configured.

Algiz 7

Click the  icon and make sure the Crew Prefs are correct, then **click** the Device Config tab and **click** Habitat, then OK.

Monument

Using a meter tape, measure the distance from the monument site to Transect A left bank. This is a straight line distance so it is important that the meter tape is level when taking this measurement. If something is blocking the path you will need to break the distance up by taking multiple measurements. Record the distance on the AREMP description and comment data form.

Transects

Bankfull widths and wetted widths and depths will be collected at all major transects using a meter tape and meter stick.

Bankfull widths

- Stretch a meter tape from the left bankfull elevation to the right bankfull elevation, ensuring that it is level and perpendicular to the bankfull channel.
- Record the width in meters (to the nearest cm, example; 1.05m) on the “Width” datasheet.

Wetted widths

- Stretch a meter tape from left wetted edge to right wetted edge, ensuring that it is level and perpendicular to the channel. Take this measurement on the same axis as the bankfull tape was strung.
- Record the width in meters (to the nearest cm) on the “Width” datasheet.

Depths

- Stretch a meter tape from left bankfull elevation to right bankfull elevation, ensuring that it is level and perpendicular to the channel. Secure each side of the meter tape with bank pins.
- Using a meter stick take depth measurements at the same ten locations across each transect (LB, 10, LW, 30, 50, TH, 70, 90, RW, RB). Place the meter stick at the correct location and record the height from the substrate to where the meter tape crosses the meter stick (to the nearest cm) on the “Depth” datasheet. Label each measurement in the provided cells in the datasheet.

Note: If the distance from the substrate to the bankfull tape is greater than a meter, use the prism pole to mark the height and then measure that height on the pole with a meter stick.

Pools

Pool length, pool maximum depth and pool tail depth will be collected using a meter stick and tape at all qualifying pools, according to the protocol (page 32).

- Pool length will be measured from the pool tail to the pool head with a meter tape, following the thalweg.
- Capture significant bends in pools by breaking up the measurements at the corners. Also, if there are obstructions along the thalweg (log jams, root wads...), do not run the meter tape up over the barrier but take multiple measurements to ensure the length is accurate.
- Record the length in meters (to the nearest cm) on the “Pools” datasheet.
- Pool tail depth and maximum depth will be measured with a meter stick at the same locations as specified in the field protocol (page 32).
- Record the longitude location (AB, BC, etc.) of the pool in the line column in the datasheet.

Note: If a pool has a maximum depth greater than a meter, use the prism pole to capture the depth. Note the location of the water's height on the prism pole and then use the meter stick to measure that height from the bottom to the appropriate location up the prism pole.

Side Channels

Survey side channels identically to the regular field protocol. Contingency datasheets titled “SC Width, SC Depth” have been created. Collect measurements as explained in the Transects section of the Contingency Protocol.

Appendix B - Invasive Species Disinfection Protocol

Invasive species are increasingly becoming a matter of concern in the Pacific Northwest. Species such as the New Zealand mud snail have been detected in stream systems of nine Western states (including Oregon's Columbia River estuary) and are steadily expanding their range. The Aquatic and Riparian Effectiveness Monitoring Program hereafter referred to as "the program," works in the field across the Northwest Forest Plan area (all federal lands from Point Reyes National Park to the Canadian border and from the Pacific Ocean to the eastern flanks of the Cascade mountains) in a variety of aquatic and terrestrial habitats. Because of the spatial extent to which the field crews travel, the potential to serve as a vector for exotic species and diseases is great. The program has proactively developed this protocol as a mechanism to reduce the potential for spreading exotic species and diseases. The procedures that follow assume that all appropriate field gear starts each trip into the field in a clean (disinfected) state.

Field Gear

Survey gear to be disinfected:

-
- | | |
|---|---|
| <ul style="list-style-type: none"> • Macroinvertebrate collection vessel • Decanting sieve • Chest waders • Shovels | <ul style="list-style-type: none"> • Macroinvertebrate net and handle • Wading boots • Neoprene booties • Fingernail brush (supplied for scrubbing mud from gear) |
|---|---|
-

Disinfection equipment provided:

Field crews	QAQC, Trend site and Recon crews
• Large 40 gallon Tupperware bin (stored at Corvallis headquarters) • Stiff bristle fingernail brush • Car wash certificates	• Propane burner stand • Propane • Stiff bristle fingernail brush • Large quart canning pot • Metal tongs • Rubber Safety Apron • Large 40 gallon Tupperware bin • Reimbursement for carwashes

Field Crews

Survey crews perform the initial visit to a watershed, surveying multiple sites but remaining within the watershed boundary the entire work stint.

1. At the site: Before leaving the stream all waders, boots, nets and net handles, carried to the site that day, will be rinsed with stream water and any mud or dirt will be scrubbed off with a stiff bristle fingernail brush.
2. At camp: The gear should be hung to dry overnight and rigorously shaken out the next morning to remove any remaining debris/organisms.
3. In Corvallis: The crew disinfects their waders, boots and nets in boiling water.
 - a. Bring water to a rolling boil in a large canning pot. Fully immerse boots (laces as well), waders, nets and net handles in large tub of boiling water for a minimum of 2 minutes.
 - b. Remove gear from tub and lie out or hang up outside for 10 to 15 minutes to remove any excess water. Hang equipment in cages over the break and allow for it to dry for the entire duration (5-6 days) between the field stints.
 - c. Before packing the bags on departure day, the crew should shake out all the waders, boots and nets to remove any residual mud or debris.

Note: These techniques only apply if the gear will have the full 5-6 days to thoroughly dry between trips in the field. If this is not the case, please refer to the steps below for QAQC and Trend crews.

QAQC, Trend Site and Reconnaissance Crews

Quality control and Trend crews will travel to multiple watersheds during a work stint, sometimes visiting two separate watersheds in one day. These steps will be completed before entering and working in a new watershed.

1. At the site: Before leaving the stream all waders, boots and nets will be rinsed and any mud or dirt will be scrubbed off.
2. At camp:
 - a. Bring water to a rolling boil using a large canning pot and propane burner stand. Completely submerge all surfaces of nets, waders, neoprene booties and boots (making sure not to miss the eyelets of the wading boots). If a piece of gear is too large to fit in the pot, pour boiling water over the gear ensuring all the surfaces have been covered with substantial amounts of the boiling water. (Boiling water is the best method found that will kill the New Zealand Mud Snail and needs to be done after each site before traveling into the next watershed.)
 - b. The gear should then be hung to dry overnight and rigorously shaken out the next morning to remove any residual mud or debris.

Vehicles

The tires and undercarriage need to be sprayed off with a high pressure hose (if available, check at a nearby government field station or office) or by going through a car wash.

QAQC, Trend site and Reconnaissance crews: The vehicle should be cleaned of mud before driving (use a high pressure commercial carwash whenever possible) into the next watershed.

Field Crews: Back in Corvallis the vehicles will be run through a car wash to ensure the undercarriage is clean and free of debris.

Firewood

When working in Humboldt, Mendocino, Lake, Sonoma, Napa, or Marin counties in California, as well as Curry County in Oregon, **do not** transport firewood or other plant materials outside of the 6th field watershed boundary. These counties have been quarantined by their respective states because of the presence of Sudden Oak Death Syndrome. Transporting firewood, soil, or plant materials can result in substantial fines and penalties. To be safe, it is best not to transport wood between any 6th field watersheds.

Appendix C– Procedure for Pressing Plants

Collect a specimen when a plant is identified as a potential invasive species and can not be identified in the field. Only collect a plant specimen if the plant is abundant in number. If only one or two plants are present, leave the plant and take photographs. Crews will be given two plant presses; one for the field and one which will be left in the vehicle. Store the “field” plant press in a plastic bag to prevent the cardboard and newspaper from getting wet. In the vehicle, keep the plant press in a warm well-ventilated area to speed up the process of drying the specimens and to prevent growth of mold.

1. The plant press consists of alternating layers of corrugated cardboard and newspaper with plywood on each side (Figure 22). The cardboard layers allow for air circulation which helps the plant specimens dry more quickly. All the layers are held together and secured with straps.




Figure 22. Schematic of a plant press for preserving plant specimens in the field.

2. When collecting a plant specimen, collect all parts of the plant including roots, stem, leaves, and flowers (if present). Clean the specimen of all debris and dirt.
3. Carefully place the collected plant specimen between two layers of newsprint. Be sure to spread the plant out so that all parts of the plant are visible. Make a note on the margin of the newspaper with the creek code, site number, date, and the suspected species name. Also make a note on the Terrestrial Invasives data form that a specimen was collected.
4. Place the newsprint layers in the plant press between two pieces of corrugated cardboard. Replace the plywood and secure the straps. Be sure to secure the straps tightly to create pressure which helps the plant specimen dry. The plant press should be kept in a warm area with good ventilation.

Appendix D – Species list and corresponding species codes

Code	Genus	Species	Common Name
Species List - Fish			
ACME	Acipenser	medirostris	Green Sturgeon
ACTR	Acipenser	transmontanus	White Sturgeon
ACAL	Acrocheilus	alutaceus	Chiselmouth
ARIN	Archoplites	interruptes	Sacramento Perch
CAOS	Catostomus	occidentalis	Sacramento Sucker
CARI	Catostomus	rimiculus	Klamath Smallscale Sucker
CASN	Catostomus	snyderi	Klamath Largescale Sucker
CASP	Catostomus	species	UNKNOWN Sucker
CASA	Catostomus	species	Salish Sucker
CHBR	Chasmistes	brevirostris	Shortnose Sucker
COAL	Cottus	aleuticus	Coast Range Sculpin
COAR	Cottus	armatus	Staghorn Sculpin
COAS	Cottus	asper	Prickly Sculpin
COAP	Cottus	asperrimus	Rough Sculpin
COGU	Cottus	gulosus	Riffle Sculpin
COKL	Cottus	klamathensis	Marbled Sculpin
COPE	Cottus	perplexus	Reticulate Sculpin
COTT	Cottus	species	UNKNOWN Sculpin
CYSP	Cyprinus	species	UNKNOWN Cyprinid
DELU	Deltistes	luxatus	Lost River Sucker
GAAC	Gasterosteus	aculeatus	Three-Spined Stickleback
GIBI	Gila	bicolor	Tui Chub
GICO	Gila	coerulea	Blue Chub
HESY	Hesperoleucus	symmetricus	California Roach
LAAY	Lamprreta	ayresi	River Lamprey
LALE	Lamprreta	lethophaga	Pit-Klamath Brook Lamprey
LARI	Lamprreta	richardsoni	Western Brook Lamprey
LASI	Lamprreta	similis	Klamath Lamprey

LASP	Lampreta	species	UNKNOWN Lamprey
LATR	Lampreta	tridentata	Pacific Lamprey
LAEX	Lavinia	exilicauda	Hitch
MYCA	Mylocheilus	caurinus	Peamouth Chub
MYCO	Mylopharodon	conocephalus	Hardhead
NOHU	Novumbra	hubbsi	Olympic Mudminnow
ONCL	Oncorhynchus	clarki	Cutthroat Trout
ONGO	Oncorhynchus	gorbuscha	Pink Salmon
ONKE	Oncorhynchus	keta	Chum Salmon
ONKI	Oncorhynchus	kisutch	Coho Salmon
ONMY	Oncorhynchus	mykiss	Rainbow Trout
ONNE	Oncorhynchus	nerka	Sockeye (Red) Salmon
ONSA	Oncorhynchus	SALMON	UNKNOWN Oncorhynchus Salmon
ONSP	Oncorhynchus	species	UNKNOWN Oncorhynchus Species
ONTR	Oncorhynchus	TROUT	UNKNOWN Oncorhynchus Trout
ONTS	Oncorhynchus	tshawytscha	Chinook Salmon
ORCR	Oregonichthys	crameri	Oregon Chub
ORKA	Oregonichthys	kalawatseti	Umpqua Chub
ORMI	Orthodon	microlepidontus	Sacramento Blackfish
PETR	Percopsis	transmontana	Sand Roller
PRWI	Prosopium	williamsoni	Mountain Whitefish
PTGR	Ptychocheilus	grandis	Sacramento Pikeminnow
PTOR	Ptychocheilus	oregonensis	Northern Pikeminnow
PTUM	Ptychocheilus	umpque	Umpqua Pikeminnow
RHCA	Rhinichthys	cataractae	Longnose Dace
RHEV	Rhinichthys	evermanni	Umpqua Dace
RHOS	Rhinichthys	osculus	Speckled Dace
RHSP	Rhinichthys	species	UNKNOWN Dace
RIBA	Richardsonius	balteatus	Red-Side Shiner
SASA	Salmo	salar	Atlantic Salmon
SATR	Salmo	trutta	Brown Trout
SALM	Salmonidae	species	UNKNOWN Salmonidae
SACO	Salvelinus	confluentus	Bull Trout

SAFO	Salvelinus	fontinalis	Brook Trout
SASP	Salvelinus	species	UNKNOWN Salvelinus Species (Bull/Brook)
THPA	Thaleichthys	pacificus	Eulachon
WWWW	UNKNOWN	FISH	UNKNOWN FISH
ZZZZ	NONE	NONE	Nothing Captured
Species List - Amphibians			
Code	Genus	Species	Common Name
AMGR	Ambystoma	gracile	Northwestern Salamander
ANFE	Aneides	ferreus	Clouded Salamander
ANPL	Aneides	flavipunctatus	Black Salamander
ASTR	Ascaphus	truei	Tailed Frog
BAWR	Batrachoseps	wrighti	Oregon Slender Salamander
BUBO	Bufo	boreus	Western Toad
DICO	Dicamptodon	copei	Cope's Giant Salamander
DIEN	Dicamptodon	ensatus	California Giant Salamander
DISP	Dicamptodon	species	Unknown Dicamptodon
DITE	Dicamptodon	tenebrosus	Coastal Giant Salamander
ENES	Ensatina	eschscholtzii	Ensatina
HYSH	Hydromantes	shastae	Shasta Salamander
UNFR	NONE	FROG	Unknown Frog
UNSA	NONE	SALAMANDAR	Unknown Salamander
UNTO	NONE	TOAD	Unknown Toad
PLDU	Plethodon	dunni	Dunn's Salamander
PLEL	Plethodon	elongatus	Del Norte Salamander
PLLA	Plethodon	larselli	Larch Mountain Salamander
PLSP	Plethodon	species	Unknown Plethodon
PLST	Plethodon	stormi	Siskiyou Mountains Salamander
PLVA	Plethodon	vandykei	Van Dyke's Salamander
PLVE	Plethodon	vehiculum	Western Red-Back Salamander
PSRE	Pseudacris	regilla	Pacific Chorus Frog
RAAU	Rana	aurora	Red-Legged Frog
RABO	Rana	boylei	Foothill Yellow-Legged Frog
RACA	Rana	cascadae	Cascades Frog

RAPR	Rana	pretiosa	Spotted Frog
RHCS	Rhyacotriton	cascadae	Cascade Torrent Salamander
RHKE	Rhyacotriton	kezeri	Columbia Torrent Salamander
RHOL	Rhyacotriton	olympicus	Olympic Torrent Salamander
RHVA	Rhyacotriton	variegatus	Southern Torrent Salamander
TAGR	Taricha	granulosa	Rough-Skinned Newt
TARI	Taricha	rivularis	Red-Bellied Newt
TASP	Taricha	species	Unknown Newt
TATO	Taricha	torosa	California Newt
YYYY	UNKNOWN	AMPHIBIAN	Unknown Species - Amphibian
XXXX	UNKNOWN	EGG MASS	Unknown Species Egg Mass
Species List- Invasive Animals			
POAN	Potamopyrgus	antipodarum	New Zealand Mudsnaills
DRPO	Dreissena	polymorpha	Zebra Mussels
DRRO	Dreissena	rostriformis	Quagga Mussels
ORRU	Orconectes	rusticus	Rusty Crayfish
ORNE	Orconectes	neglectus	Ringed Crayfish
ORVI	Orconectes	virilis	Northern Crayfish
PRCL	Procambarus	clarkia	Red Swamp Crayfish
SUSC	Sus	scrofa	Feral Swine

References

- Adams, J. and L. Mannik. 1998. Impulse LR: User's Manual. Laser Technology, Inc., United States of America. 80 p.
- Harrelson, C. C., C. L. Rawlins, and J. P. Potyondy. 1994. Stream channel reference sites: an illustrated guide to field technique. Gen. Tech. Rep. RM-245. Fort Collins, CO: U.S. Department of Agriculture, Forest Service, Rocky Mountain Forest and Range Experiment Station. 61 p.
- Hawkins, C. P., J. Ostermiller, and M. Vinson. 2001. Stream invertebrate, periphyton, and environmental sampling associated with biological water quality assessments. Field Protocols. Utah State University, Logan, UT.
- Henderson, Rick. 2001. Effectiveness monitoring of streams and riparian areas within the Upper Columbia River Basin: Sampling Protocol for Integrator Reaches (Draft). Fish Ecology Unit – U.S. Forest Service Effectiveness Monitoring Team, Logan, UT
- Moore K, K. Jones, and J. Dambacher. 1999. Methods for stream habitat surveys, aquatic habitat inventory project, Natural Production Program: Oregon Department of Fish and Wildlife, Corvallis, OR.
- Palmer, C.J. In preparation. Quality System Management Plan for Environmental Data Collection Projects, Interagency Regional Monitoring, Northwest Forest Plan.
- Peck, D. V., J. M. Lazorchak, and D. J. Klemm (editors). Unpublished draft. Environmental monitoring and assessment program – surface waters: Western pilot study field operations manual for wadeable streams. EPA/XXX/X-XX/XXXX. U.S. Environmental Protection Agency, Washington, D.C.
- Pleus, A.E. and D. Schuett-Hames. 1998a. TFW Monitoring Program methods manual for stream segment identification. Prepared for the Washington State Dept. of Natural Resources under the Timber, Fish, and Wildlife Agreement. TFW-AM9-98-001. DNR #103. May.
- Pleus, A.E. and D. Schuett-Hames. 1998b. TFW Monitoring Program methods manual for the reference point survey. Prepared for the Washington State Dept. of Natural Resources under the Timber, Fish, and Wildlife Agreement. TFW-AM9-98-002. DNR #104. May.
- Pleus, A.E. and D. Schuett-Hames. 1999. TFW Monitoring Program methods manual for the habitat survey. Prepared for the Washington State Dept. of Natural Resources under the Timber, Fish, and Wildlife Agreement. TFW-AM9-99-003. DNR #105. June.
- Rosgen, Dave. Applied River Morphology. Pagosa Springs, Colorado: Wildland Hydrology, 1996.

NOTES

NOTES